

ASTON MARTIN

Legend

PAR = Parameters

ATT = Check Components (Active Diagnosis)

COD = Adaptation and Coding

DIAG = Diagnosis

■ = Supported

A = Self recognition (function available if the module is recognized by the diagnostic tool)

1-77 (From 2009)

MODULE	DIAG	PAR	ATT	COD
Transmission Module	■	■	■	■
Audio Amplifier	■	■	■	■
Centre console module	■	■	■	■
Central Electronic Module High	■	■	■	■
Central Electronic Module Low	■	■	■	■
Drivers door module	■	■	■	■
Driver Information Module	■	■	■	■
Driver seat module	■	■	■	■
EBS - Electronic Brake Control Module - EBS	■	■	■	■
12 Cylinder EMS-P - Engine Control Module - Bank 1	■	■	■	■
12 Cylinder EMS-S - Engine Control Module - Bank 2	■	■	■	■
Parking brake	■	■	■	■
Steering Column	■	■	■	■
Infotainment Control Unit	■	■	■	■
Passenger door module	■	■	■	■
Passenger seat module	■	■	■	■
RCM - Restraints Control Module - RCM	■	■	■	■
Steering Angle Sensor	■	■	■	■
Tyre pressure monitoring	■	■	■	■

Cygnnet (From 2011)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping Module	█	█		█
AM/FM Tuner Module	█			█
ASM - Marelli transmission control module	█	█	█	
Audio Amplifier	█		█	█
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module - BCM	█	█		█
Bluetooth Phone	█	█		█
CCM - Centre console module before 2008	█			█
CCM - Centre console module after 2008	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
Convertible Roof	█	█		█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver door module rear	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
8 Cylinder ECM - Engine Control Module - Bank 1	█	█		█
Parking brake	█			█
Steering Column	█	█		█
Front console interface	█			█
Global Positioning System	█			█
Headlamp Levelling	█	█		█
LCD module	█			█
Multi-Media Module	█	█		█
Media Player Module	█			█
Parking Aid Module	█	█		█
PDM+ - Passenger door module	█	█		█
PDM - Passenger door module	█	█		█
Passenger door module rear	█	█		█
Passenger seat module	█	█		█
Rear console interface	█			█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Sub Woofer Amplifier	█			█
TCMZF - Transmission Control Module	█	█		█
Tyre pressure monitoring	█		█	█

DB11 AMR (From 2018)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Body Controller Front	█	█		█
Body Controller Rear	█	█		█
Blind Spot Monitoring Master	█			█
Blind Spot Monitoring Slave	█			█
Common Powertrain Control Module	█	█	█	█
Centre Stack Panel	█			█
Central Controls	█	█		█
Central Display	█			█
Door Module Front Left	█			█
Door Module front Right	█			█
Drive Unit	█	█	█	█
ECM1 - Engine Control Module V12 Master	█	█	█	█
ECM2 - Engine Control Module V12 Slave	█	█		█
Electronic Ignition Switch	█	█		█
Electronic Power Steering Module	█	█		█
Electronic Stability and Park Brake Module - ESP	█	█	█	█
Fuel System Control Module	█	█		█
Telematic Gateway Head Unit	█			█
HVAC Module	█	█		█
Instrument Cluster	█	█		█
Intrusion Sensor 1	█	█		█
Intrusion Sensor 2	█	█		█
Keyless Go Module	█			█
Light/Rain Sensor	█	█		█
Occupant Restraints Controller - ORC	█	█		█
Parking Control Module	█	█		█
Left Door Switch Module Memory Seat	█	█		█
Right Door Switch Module Memory Seat	█			█
Steering Column Control Module	█			█
Seat Module Drivers	█	█		█
Seat Module Passenger	█	█		█
Alarm Siren	█	█		█
Suspension Control Module	█	█		█
Surround View System	█			█
Transmission Control Module	█	█		█
Touch Pad	█			█
Tyre Pressure Monitor Module	█	█		█
Vehicle Theft Alarm Sensor Module	█			█
Left Door Switch Module Window/Mirror	█	█		█
Right Door Switch Module Window/Mirror	█			█
Wiper Motor	█			█

DB11 Coupe (From 2016)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Body Controller Front	█	█		█
Body Controller Rear	█	█		█
Blind Spot Monitoring Master	█			█
Blind Spot Monitoring Slave	█			█
Common Powertrain Control Module	█	█	█	█
Centre Stack Panel	█			█
Central Controls	█	█		█
Central Display	█			█
Door Module Front Left	█			█
Door Module front Right	█			█
Drive Unit	█	█	█	█
ECM1 - Engine Control Module V12 Master	█	█	█	█
ECM2 - Engine Control Module V12 Slave	█	█		█
ECM_V8 - Engine Control Module V8	█		█	█
Electronic Ignition Switch	█	█		█
Electronic Power Steering Module	█	█		█
Electronic Stability and Park Brake Module - ESP	█		█	█
Fuel System Control Module	█	█		█
Telematic Gateway Head Unit	█			█
HVAC Module	█	█		█
Instrument Cluster	█	█		█
Intrusion Sensor 1	█	█		█
Intrusion Sensor 2	█	█		█
Keyless Go Module	█			█
Light/Rain Sensor	█	█		█
Occupant Restraints Controller - ORC	█	█		█
Parking Control Module	█	█		█
Left Door Switch Module Memory Seat	█	█		█
Right Door Switch Module Memory Seat	█			█
Steering Column Control Module	█			█
Seat Module Drivers	█	█		█
Seat Module Passenger	█	█		█
Alarm Siren	█	█		█
Suspension Control Module	█	█		█
Surround View System	█			█
Transmission Control Module	█	█		█
Touch Pad	█			█
Tyre Pressure Monitor Module	█	█		█
Vehicle Theft Alarm Sensor Module	█			█
Left Door Switch Module Window/Mirror	█	█		█
Right Door Switch Module Window/Mirror	█			█
Wiper Motor	█			█

DB11 Volante (From 2018)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Body Controller Front	█	█		█
Body Controller Rear	█	█		█
Blind Spot Monitoring Master	█			█
Blind Spot Monitoring Slave	█			█
Common Powertrain Control Module	█	█	█	█
Convertible Roof Module	█	█		█
Centre Stack Panel	█			█
Central Controls	█	█		█
Central Display	█			█
Door Module Front Left	█			█
Door Module front Right	█			█
Drive Unit	█	█	█	█
ECM_V8 - Engine Control Module V8 - ECM_V8	█	█	█	█
Electronic Ignition Switch	█	█		█
Electronic Power Steering Module	█	█		█
Electronic Stability and Park Brake Module - ESP	█	█	█	█
Fuel System Control Module	█	█		█
Telematic Gateway Head Unit	█			█
HVAC Module	█	█		█
Instrument Cluster	█	█		█
Intrusion Sensor 1	█	█		█
Intrusion Sensor 2	█	█		█
Keyless Go Module	█			█
Light/Rain Sensor	█	█		█
Occupant Restraints Controller - ORC	█	█		█
Parking Control Module	█	█		█
Left Door Switch Module Memory Seat	█	█		█
Right Door Switch Module Memory Seat	█			█
Steering Column Control Module	█			█
Seat Module Drivers	█	█		█
Seat Module Passenger	█	█		█
Alarm Siren	█	█		█
Suspension Control Module	█	█		█
Surround View System	█			█
Transmission Control Module	█	█		█
Touch Pad	█			█
Tyre Pressure Monitor Module	█	█		█
Vehicle Theft Alarm Sensor Module	█			█
Left Door Switch Module Window/Mirror	█	█		█
Right Door Switch Module Window/Mirror	█			█
Wiper Motor	█			█

DB9 (From 2004)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping Module	█	█		█
AM/FM Tuner Module	█			█
ASM - Marelli transmission control module	█	█	█	
Audio Amplifier	█		█	█
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module - BCM	█	█		█
Bluetooth Phone	█	█		█
CCM - Centre console module before 2008	█			█
CCM - Centre console module after 2008	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
Convertible Roof	█	█		█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver door module rear	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
8 Cylinder ECM - Engine Control Module - Bank 1	█	█		█
Parking brake	█			█
Steering Column	█	█		█
Front console interface	█			█
Global Positioning System	█			█
Headlamp Levelling	█	█		█
LCD module	█			█
Multi-Media Module	█	█		█
Media Player Module	█			█
Parking Aid Module	█	█		█
PDM+ - Passenger door module	█	█		█
PDM - Passenger door module	█	█		█
Passenger door module rear	█	█		█
Passenger seat module	█	█		█
Rear console interface	█			█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Sub Woofer Amplifier	█			█
TCMZF - Transmission Control Module	█	█		█
Tyre pressure monitoring	█		█	█

DBS Superleggera (From 2018)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Body Controller Front	█	█		█
Body Controller Rear	█	█		█
Blind Spot Monitoring Master	█			█
Blind Spot Monitoring Slave	█			█
Common Powertrain Control Module	█	█	█	█
Centre Stack Panel	█			█
Central Controls	█	█		█
Central Display	█			█
Door Module Front Left	█			█
Door Module front Right	█			█
Drive Unit	█	█	█	█
ECM1 - Engine Control Module V12 Master	█	█	█	█
ECM2 - Engine Control Module V12 Slave	█	█		█
Electronic Ignition Switch	█	█		█
Electronic Power Steering Module	█	█		█
Electronic Stability and Park Brake Module - ESP	█	█	█	█
Fuel System Control Module	█	█		█
Telematic Gateway Head Unit	█			█
HVAC Module	█	█		█
Instrument Cluster	█	█		█
Intrusion Sensor 1	█	█		█
Intrusion Sensor 2	█	█		█
Keyless Go Module	█			█
Light/Rain Sensor	█	█		█
Occupant Restraints Controller - ORC	█	█		█
Parking Control Module	█	█		█
Left Door Switch Module Memory Seat	█	█		█
Right Door Switch Module Memory Seat	█			█
Steering Column Control Module	█			█
Seat Module Drivers	█	█		█
Seat Module Passenger	█	█		█
Alarm Siren	█	█		█
Suspension Control Module	█	█		█
Surround View System	█			█
Transmission Control Module	█	█		█
Touch Pad	█			█
Tyre Pressure Monitor Module	█	█		█
Vehicle Theft Alarm Sensor Module	█			█
Left Door Switch Module Window/Mirror	█	█		█
Right Door Switch Module Window/Mirror	█			█
Wiper Motor	█			█

DBS Superleggera OHMSS (From 2019)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Body Controller Front	█	█		█
Body Controller Rear	█	█		█
Blind Spot Monitoring Master	█			█
Blind Spot Monitoring Slave	█			█
Common Powertrain Control Module	█	█	█	█
Centre Stack Panel	█			█
Central Controls	█	█		█
Central Display	█			█
Door Module Front Left	█			█
Door Module front Right	█			█
Drive Unit	█	█	█	█
ECM1 - Engine Control Module V12 Master	█	█	█	█
ECM2 - Engine Control Module V12 Slave	█	█		█
Electronic Ignition Switch	█	█		█
Electronic Power Steering Module	█	█		█
Electronic Stability and Park Brake Module - ESP	█	█	█	█
Fuel System Control Module	█	█		█
Telematic Gateway Head Unit	█			█
HVAC Module	█	█		█
Instrument Cluster	█	█		█
Intrusion Sensor 1	█	█		█
Intrusion Sensor 2	█	█		█
Keyless Go Module	█			█
Light/Rain Sensor	█	█		█
Occupant Restraints Controller - ORC	█	█		█
Parking Control Module	█	█		█
Left Door Switch Module Memory Seat	█	█		█
Right Door Switch Module Memory Seat	█			█
Steering Column Control Module	█			█
Seat Module Drivers	█	█		█
Seat Module Passenger	█	█		█
Alarm Siren	█	█		█
Suspension Control Module	█	█		█
Surround View System	█			█
Transmission Control Module	█	█		█
Touch Pad	█			█
Tyre Pressure Monitor Module	█	█		█
Vehicle Theft Alarm Sensor Module	█			█
Left Door Switch Module Window/Mirror	█	█		█
Right Door Switch Module Window/Mirror	█			█
Wiper Motor	█			█

DBS Superleggera Volante (From 2019)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Body Controller Front	█	█		█
Body Controller Rear	█	█		█
Blind Spot Monitoring Master	█			█
Blind Spot Monitoring Slave	█			█
Common Powertrain Control Module	█	█	█	█
Convertible Roof Module	█	█		█
Centre Stack Panel	█			█
Central Controls	█	█		█
Central Display	█			█
Door Module Front Left	█			█
Door Module front Right	█			█
Drive Unit	█	█	█	█
ECM1 - Engine Control Module V12 Master	█	█	█	█
ECM2 - Engine Control Module V12 Slave	█	█		█
Electronic Ignition Switch	█	█		█
Electronic Power Steering Module	█	█		█
Electronic Stability and Park Brake Module - ESP	█		█	█
Fuel System Control Module	█	█		█
Telematic Gateway Head Unit	█			█
HVAC Module	█	█		█
Instrument Cluster	█	█		█
Intrusion Sensor 1	█	█		█
Intrusion Sensor 2	█	█		█
Keyless Go Module	█			█
Light/Rain Sensor	█	█		█
Occupant Restraints Controller - ORC	█	█		█
Parking Control Module	█	█		█
Left Door Switch Module Memory Seat	█	█		█
Right Door Switch Module Memory Seat	█			█
Steering Column Control Module	█			█
Seat Module Drivers	█	█		█
Seat Module Passenger	█	█		█
Alarm Siren	█	█		█
Suspension Control Module	█	█		█
Surround View System	█			█
Transmission Control Module	█	█		█
Touch Pad	█			█
Tyre Pressure Monitor Module	█	█		█
Vehicle Theft Alarm Sensor Module	█			█
Left Door Switch Module Window/Mirror	█	█		█
Right Door Switch Module Window/Mirror	█			█
Wiper Motor	█			█

DBS V12 (From 2007)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping Module	█	█		█
AM/FM Tuner Module	█			█
ASM - Marelli transmission control module	█	█	█	
Audio Amplifier	█		█	█
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module - BCM	█	█		█
Bluetooth Phone	█	█		█
CCM - Centre console module before 2008	█			█
CCM - Centre console module after 2008	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
Convertible Roof	█	█		█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver door module rear	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
8 Cylinder ECM - Engine Control Module - Bank 1	█	█		█
Parking brake	█			█
Steering Column	█	█		█
Front console interface	█			█
Global Positioning System	█			█
Headlamp Levelling	█	█		█
LCD module	█			█
Multi-Media Module	█	█		█
Media Player Module	█			█
Parking Aid Module	█	█		█
PDM+ - Drivers door module	█	█		█
PDM - Drivers door module	█	█		█
Passenger door module rear	█	█		█
Passenger seat module	█	█		█
Rear console interface	█			█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Sub Woofer Amplifier	█			█
TCMZF - Transmission Control Module	█	█		█
Tyre pressure monitoring	█		█	█

DBX (From 2019)

MODULE	DIAG	PAR	ATT	COD
Adaptive damping module	█	█		█
Ambient lighting control	█	█		
Body controller front	█	█		
Body controller rear	█	█		
Blind spot monitoring master	█	█		
Blind spot monitoring slave	█	█		
Centre console module	█	█		
Common powertrain control module	█	█		
Transmission centre diff	█	█		
Central controls	█	█		
DC-DC convertor 48V	█	█		
Central display	█	█		
Door module front left	█	█		
Door module front right	█	█		
Door module rear left	█	█		
Door module rear right	█	█		
Drive unit	█	█	█	
Front anti-roll controller	█	█		
Rear anti-roll controller	█	█		
ECM_V8 - Engine Control Module V8	█	█	█	
Electronic diff	█	█		
Electronic ignition switch	█	█		
Electronic power steering module	█	█		
Electronic Stability and Park Brake Module - ESP23	█	█		
Fuel system control module	█	█		
Hands free access	█	█		
Headlamp module left	█	█		
Headlamp module right	█	█		
Telematic gateway head unit	█	█		
HVAC module	█	█		
Rear HVAC panel	█	█		
Instrument Cluster Version 2	█	█		
Instrument Cluster Version 1	█	█		
Intrusion sensor 1	█	█		
Intrusion sensor 2	█	█		
Intrusion sensor 3	█	█		
Intrusion sensor 4	█	█		
Keyless go module	█	█		
Multi-purpose camera	█	█		
Occupancy sensing module	█	█		
Occupant Restraints Controller - ORC23	█	█		
Park and surround view system	█	█		
Power trunk closure module	█	█		
Solo distronic radar front	█	█		
Steering column control module	█	█		
Seat module drivers	█	█		
Seat module passenger	█	█		
Rear seat heat	█	█		
Alarm siren	█	█		
Amplifier	█	█		
Steering wheel module	█	█		
Transmission control module	█	█		
Trailer module	█	█		
Touch pad	█	█		
Tyre pressure monitor module	█	█		
TV tuner	█	█		
Vehicle climate sensor	█	█		
Vehicle theft alarm sensor module	█	█		
Wireless module interface	█	█		

Rapide (From 2009)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping Module	█	█		█
AM/FM Tuner Module	█			█
ASM - Marelli transmission control module	█	█	█	█
Audio Amplifier	█		█	█
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module - BCM	█	█		█
Bluetooth Phone	█	█		█
CCM - Centre console module before 2008	█			█
CCM - Centre console module after 2008	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
Convertible Roof	█	█		█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver door module rear	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
8 Cylinder ECM - Engine Control Module - Bank 1	█	█		█
Parking brake	█			█
Steering Column	█	█		█
Front console interface	█			█
Global Positioning System	█			█
Headlamp Levelling	█	█		█
LCD module	█			█
Multi-Media Module	█	█		█
Media Player Module	█			█
Parking Aid Module	█	█		█
PDM+ - Drivers door module	█	█		█
PDM - Drivers door module	█	█		█
Passenger door module rear	█	█		█
Passenger seat module	█	█		█
Rear console interface	█			█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Sub Woofer Amplifier	█			█
TCMZF - Transmission Control Module	█	█		█
Tyre pressure monitoring	█		█	█

Rapide S (From 2013)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping Module	█	█		█
BECM-M - 5.9L V12 Bosch Engine Control Module - Master	█	█		█
BECM-S - 5.9L V12 Bosch Engine Control Module - Slave	█	█		█
Central Electronic High	█	█		█
Central Electronic Low	█	█		█
Driver Door	█	█		█
Driver Information	█	█		█
Driver seat module	█	█		█
Parking brake	█	█		█
Steering Column	█	█		█
Front console interface	█	█		█
Integrated Audio	█	█		█
Multi Media	█	█		█
Parking Aid Module	█	█		█
Passenger Door	█	█		█
Passenger seat module	█	█		█
Rear console interface	█	█		█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Automatic Transmission	█	█	█	█
Tyre pressure monitoring	█	█	█	█

V12 Zagato (From 2011)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module - BCM	█	█		█
Bluetooth Phone	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
8 Cylinder ECM - Engine Control Module - Bank 1	█	█		█
Steering Column	█	█		█
Headlamp Levelling	█	█		█
Integrated Audio	█	█		█
Multi-Media Module	█	█		█
Parking Aid Module	█	█		█
PDM+ - Drivers door module	█	█		█
PDM - Drivers door module	█	█		█
Passenger seat module	█	█		█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Satellite Digital Radio Module	█	█	█	█
Tyre pressure monitoring	█	█	█	█

Vanquish AM310 (From 2012)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping	█	█		█
BECM-M - 5.9L V12 Bosch Engine Control Module - Master	█	█		█
BECM-S - 5.9L V12 Bosch Engine Control Module - Slave	█	█		█
Central Electronic High	█	█		█
Central Electronic Low	█	█		█
Driver Door	█	█		█
Driver Information Module	█	█		█
Driver Seat	█	█		█
Integrated Audio	█	█		█
Multi Media	█	█		█
Parking Aid	█	█		█
Passenger Door	█	█		█
Passenger Seat	█	█		█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Automatic Transmission	█	█	█	█
Tyre pressure monitoring	█	█	█	█

Vanquish AM310 Volante (From 2012)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping	█	█		█
BECM-M - 5.9L V12 Bosch Engine Control Module - Master	█	█		█
BECM-S - 5.9L V12 Bosch Engine Control Module - Slave	█	█		█
Central Electronic High	█	█		█
Central Electronic Low	█	█		█
Convertible Roof	█	█		█
Driver Door	█	█		█
Driver Information Module	█	█		█
Driver Seat	█	█		█
Integrated Audio	█	█		█
Multi Media	█	█		█
Parking Aid	█	█		█
Passenger Door	█	█		█
Passenger Seat	█	█		█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Automatic Transmission	█	█	█	█
Tyre pressure monitoring	█	█	█	█

Vanquish S Coupe (2012-2018)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping Module	█	█		█
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module	█	█		█
Bluetooth Phone	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
EBS - Electronic Brake Control Module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
Steering Column	█	█		█
Headlamp Levelling	█	█		█
Integrated Audio	█	█		█
Multi-Media Module	█	█		█
Parking Aid Module	█	█		█
PDM+ - Drivers door module	█	█		█
PDM - Drivers door module	█	█		█
Passenger seat module	█	█		█
RCM - Restraints Control Module - RCM	█	█		█
Ride Height Control Module	█		█	█
Steering Angle Sensor	█	█		█
Satellite Digital Radio Module	█	█		█
Automatic Transmission	█	█		█
Tyre pressure monitoring	█		█	█

Vanquish S Volante (2013-2018)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping Module	█	█		█
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module	█	█		█
Bluetooth Phone	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
Convertible Roof	█	█		█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
EBS - Electronic Brake Control Module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
Steering Column	█	█		█
Headlamp Levelling	█	█		█
Integrated Audio	█	█		█
Multi-Media Module	█	█		█
Parking Aid Module	█	█		█
PDM+ - Drivers door module	█	█		█
PDM - Drivers door module	█	█		█
Passenger seat module	█	█		█
RCM - Restraints Control Module - RCM	█	█		█
Ride Height Control Module	█		█	█
Steering Angle Sensor	█	█		█
Satellite Digital Radio Module	█	█		█
Automatic Transmission	█	█		█
Tyre pressure monitoring	█		█	█

Vanquish V12 (From 2001)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Transmission Module Marelli	■	■	■	■

Vanquish Zagato (From 2017)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping Module	■	■		■
Auxiliary USB Unit	■	■		■
BCM - Brake Control Module - BCM	■	■		■
BECM-M - 5.9L V12 Bosch Engine Control Module - Master	■	■		■
BECM-S - 5.9L V12 Bosch Engine Control Module - Slave	■	■		■
Bluetooth Phone	■	■		■
Central Electronic Module High	■	■		■
Central Electronic Module Low	■	■		■
DDM+ - Drivers door module	■	■		■
DDM - Drivers door module	■	■		■
Driver Information Module	■	■		■
Driver seat module	■	■		■
12 Cylinder EMS-P - Engine Control Module - Bank 1	■	■		■
12 Cylinder EMS-S - Engine Control Module - Bank 2	■	■		■
8 Cylinder ECM - Engine Control Module - Bank 1	■	■		■
Steering Column	■	■		■
Headlamp Levelling	■	■		■
Integrated Audio	■	■		■
Multi-Media Module	■	■		■
Parking Aid Module	■	■		■
PDM+ - Drivers door module	■	■		■
PDM - Drivers door module	■	■		■
Passenger seat module	■	■		■
RCM - Restraints Control Module - RCM	■	■		■
Ride Height Control Module	■		■	■
Steering Angle Sensor	■	■		■
Satellite Digital Radio Module	■	■		■
Automatic Transmission	■	■		■
Tyre pressure monitoring	■	■	■	■

Vantage (From 2005)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping Module	█	█		█
AM/FM Tuner Module	█			█
ASM - Marelli transmission control module	█	█	█	█
Audio Amplifier	█		█	█
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module - BCM	█	█		█
Bluetooth Phone	█	█		█
CCM - Centre console module before 2008	█	█		█
CCM - Centre console module after 2008	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver door module rear	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
8 Cylinder ECM - Engine Control Module - Bank 1	█	█		█
Parking brake	█	█		█
Steering Column	█	█		█
Front console interface	█			█
Global Positioning System	█			█
Headlamp Levelling	█	█		█
LCD module	█			█
Multi-Media Module	█	█		█
Media Player Module	█	█		█
Parking Aid Module	█	█		█
PDM+ - Drivers door module	█	█		█
PDM - Drivers door module	█	█		█
Passenger door module rear	█	█		█
Passenger seat module	█	█		█
Rear console interface	█			█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Sub Woofer Amplifier	█	█		█
TCMZP - Transmission Control Module	█	█		█
Tyre pressure monitoring	█	█	█	█

Vantage Coupe (From 2018)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Body Controller Front	█	█		█
Body Controller Rear	█	█		█
Blind Spot Monitoring Master	█			█
Blind Spot Monitoring Slave	█			█
Common Powertrain Control Module	█	█	█	█
Centre Stack Panel	█			█
Central Controls	█	█		█
Central Display	█			█
Door Module Front Left	█			█
Door Module front Right	█			█
Drive Unit	█	█	█	█
ECM_V8 - Engine Control Module V8 - ECM_V8	█	█	█	█
Electronic Diff	█	█		█
Electronic Ignition Switch	█	█		█
Electronic Power Steering Module	█	█		█
Electronic Stability and Park Brake Module - ESP	█	█	█	█
Fuel System Control Module	█	█		█
Telematic Gateway Head Unit	█			█
HVAC Module	█	█		█
Instrument Cluster	█	█		█
Intrusion Sensor 1	█	█		█
Intrusion Sensor 2	█	█		█
Keyless Go Module	█			█
Light/Rain Sensor	█	█		█
Occupant Restraints Controller - ORC	█	█		█
Parking Control Module	█	█		█
Left Door Switch Module Memory Seat	█	█		█
Right Door Switch Module Memory Seat	█			█
Steering Column Control Module	█			█
Seat Module Drivers	█	█		█
Seat Module Passenger	█	█		█
Alarm Siren	█	█		█
Suspension Control Module	█	█		█
Surround View System	█			█
Transmission Control Module	█	█		█
Touch Pad	█			█
Tyre Pressure Monitor Module	█	█		█
Vehicle Theft Alarm Sensor Module	█			█
Left Door Switch Module Window/Mirror	█	█		█
Right Door Switch Module Window/Mirror	█			█
Wiper Motor	█			█

Vantage Roadster (From 2007)

MODULE	DIAG	PAR	ATT	COD
Adaptive Damping Module	█	█		█
AM/FM Tuner Module	█			█
ASM - Marelli transmission control module	█	█	█	
Audio Amplifier	█		█	█
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module - BCM	█	█		█
Bluetooth Phone	█	█		█
CCM - Centre console module before 2008	█			█
CCM - Centre console module after 2008	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
Convertible Roof	█	█		█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver door module rear	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
8 Cylinder ECM - Engine Control Module - Bank 1	█	█		█
Parking brake	█			█
Steering Column	█	█		█
Front console interface	█			█
Global Positioning System	█			█
Headlamp Levelling	█	█		█
LCD module	█			█
Multi-Media Module	█	█		█
Media Player Module	█			█
Parking Aid Module	█	█		█
PDM+ - Drivers door module	█	█		█
PDM - Drivers door module	█	█		█
Passenger door module rear	█	█		█
Passenger seat module	█	█		█
Rear console interface	█			█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Sub Woofer Amplifier	█			█
TCMZF - Transmission Control Module	█	█		█
Tyre pressure monitoring	█		█	█

Vantage S (From 2011)

MODULE	DIAG	PAR	ATT	COD
Adaptive Damping Module	█	█		█
AM/FM Tuner Module	█			█
ASM - Marelli transmission control module	█	█	█	
Audio Amplifier	█		█	█
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module - BCM	█	█		█
BECM-M - 5.9L V12 Bosch Engine Control Module - Master	█	█		█
BECM-S - 5.9L V12 Bosch Engine Control Module - Slave	█	█		█
Bluetooth Phone	█	█		█
CCM - Centre console module before 2008	█			█
CCM - Centre console module after 2008	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver door module rear	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
8 Cylinder ECM - Engine Control Module - Bank 1	█	█		█
Parking brake	█	█		█
Steering Column	█	█		█
Front console interface	█			█
Global Positioning System	█			█
Headlamp Levelling	█	█		█
LCD module	█	█		█
Multi-Media Module	█	█		█
Media Player Module	█	█		█
Parking Aid Module	█	█		█
PDM+ - Drivers door module	█	█		█
PDM - Drivers door module	█	█		█
Passenger door module rear	█	█		█
Passenger seat module	█	█		█
Rear console interface	█			█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Sub Woofer Amplifier	█	█		█
TCMZP - Transmission Control Module	█	█	█	█
Tyre pressure monitoring	█	█	█	█

Vantage S Roadster (From 2011)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping Module	█	█		█
AM/FM Tuner Module	█			█
ASM - Marelli transmission control module	█	█	█	
Audio Amplifier	█		█	█
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module - BCM	█	█		█
BECM-M - 5.9L V12 Bosch Engine Control Module - Master	█	█		█
BECM-S - 5.9L V12 Bosch Engine Control Module - Slave	█	█		█
Bluetooth Phone	█	█		█
CCM - Centre console module before 2008	█			█
CCM - Centre console module after 2008	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
Convertible Roof	█			█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver door module rear	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
8 Cylinder ECM - Engine Control Module - Bank 1	█	█		█
Parking brake	█	█		█
Steering Column	█	█		█
Front console interface	█			█
Global Positioning System	█			█
Headlamp Levelling	█	█		█
LCD module	█			█
Multi-Media Module	█	█		█
Media Player Module	█			█
Parking Aid Module	█	█		█
PDM+ - Drivers door module	█	█		█
PDM - Drivers door module	█	█		█
Passenger door module rear	█	█		█
Passenger seat module	█	█		█
Rear console interface	█			█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Sub Woofer Amplifier	█			█
TCMZP - Transmission Control Module	█	█	█	█
Tyre pressure monitoring	█	█	█	█

Virage (From 2011)

<i>MODULE</i>	<i>DIAG</i>	<i>PAR</i>	<i>ATT</i>	<i>COD</i>
Adaptive Damping Module	█	█		█
AM/FM Tuner Module	█			█
ASM - Marelli transmission control module	█	█	█	█
Audio Amplifier	█		█	█
Auxiliary USB Unit	█	█		█
BCM - Brake Control Module - BCM	█	█		█
Bluetooth Phone	█	█		█
CCM - Centre console module before 2008	█	█		█
CCM - Centre console module after 2008	█	█		█
Central Electronic Module High	█	█		█
Central Electronic Module Low	█	█		█
Convertible Roof	█	█		█
DDM+ - Drivers door module	█	█		█
DDM - Drivers door module	█	█		█
Driver door module rear	█	█		█
Driver Information Module	█	█		█
Driver seat module	█	█		█
12 Cylinder EMS-P - Engine Control Module - Bank 1	█	█		█
12 Cylinder EMS-S - Engine Control Module - Bank 2	█	█		█
8 Cylinder ECM - Engine Control Module - Bank 1	█	█		█
Parking brake	█	█		█
Steering Column	█	█		█
Front console interface	█	█		█
Global Positioning System	█	█		█
Headlamp Levelling	█	█		█
LCD module	█	█		█
Multi-Media Module	█	█		█
Media Player Module	█	█		█
Parking Aid Module	█	█		█
PDM+ - Drivers door module	█	█		█
PDM - Drivers door module	█	█		█
Passenger door module rear	█	█		█
Passenger seat module	█	█		█
Rear console interface	█	█		█
RCM - Restraints Control Module - RCM	█	█		█
Steering Angle Sensor	█	█		█
Sub Woofer Amplifier	█	█		█
TCMZF - Transmission Control Module	█	█		█
Tyre pressure monitoring	█	█	█	█